SMART Slate Training

Overview

What is a SMART Slate?

- Hardware
- Peripherals

Setting up your Slate

- Pen Tether/Bluetooth Storage
- Charging
  - What do the lights mean?

Power LED State	Description
Green	The battery is fully charged. OR The USB charging cable is connected to your computer and your computer is powering by your slate.
Amber and Blinking Amber	The battery charge is low. Connect the USB charging cable to charge the battery.
Red and Blinking Red	The battery is completely drained. Connect the USB charging cable to charge the battery.
Off	The battery isn't connected. Check the battery compartment and ensure the battery is properly installed. OR The battery insulation film is in the battery compartment. Remove the battery insulating film (see page 7).

Status LED State	Description
Green	Your slate is connected to your computer.
Dark Green	The pen is touching the workspace.
Blinking Green	The slate is searching for your computer to create a wireless connection.
Amber	The slate was once connected to your computer, but the wireless connection is lost.

Using your Slate

- Connecting the Slate to your Computer
- Slate Buttons
- Pen Buttons/Functions
- Icon Strip

Customizing your Slate

- SMART Notebook Control Panel
  - Customizing:
    - Pen
    - Slate
    - Icon Strip/Paper Underlay

Tips

- Once you connoect your Slate to your computer once, you never need to press "connect" again. It will automatically find your Slate for you. If you do press connect, you will need to open your Bluetooth settings on your computer, delete the Slate, and reconnect.

- Print your Paper Underlay to access different features of the Slate/Notebook software on the fly.

- Change the functions of all your "buttons" on each piece of equipment using the SMART Notebook Control Panel on your computer desktop – this will come in handy especially once you get used to using the Slate.

Kerry Guiliano – guilianok@southfield.k12.mi.us
Technology Integration Specialist
Handout located at **ostsedtech.weebly.com**